



01. 현수막봉 (PLACARD BATTEN)
02. 면막 (MAIN CURTAIN)
03. 조명봉 1 (#1 LIGHT BATTEN)
04. 보더라이트 1(#1 BORDER LIGHT)
05. 06. 측면을향반사판 1, 2 (#1, 2 ACOUSTICAL SHELL-SIDE WALL)
07. 천장을향반사판 1 (#1 ACOUSTICAL SHELL-CEILING)
08. 09. 다리막 1, 2 (#1, 2 HOUSE LEG)
10. 장치봉 1 (#1 SET BATTEN)
11. 조명봉 2 (#2 LIGHT BATTEN)
12. 보더라이트 2 (#2 BORDER LIGHT)
13. 끝막 1 (#1 DRAW CURTAIN)
14. 영사막 (SCREEN)
15. 장치봉 2 (#2 SET BATTEN)
16. 17. 측면을향반사판 3, 4 (#3, 4 ACOUSTICAL SHELL-SIDE WALL)
18. 천장을향반사판 2 (#2 ACOUSTICAL SHELL-CEILING)
19. 20. 다리막 3, 4 (#3, 4 HOUSE LEG)
21. 조명봉 3 (#3 LIGHT BATTEN)
22. 후면을향반사판 (ACOUSTICAL SHELL-BACK WALL)
23. 끝막 3 (#3 DRAW CURTAIN)
24. 장치봉 3(#3 SET BATTEN)
25. 태극기봉 (FLAG BATTEN)
26. 끝막 2 (#2 DRAW CURTAIN)
27. 하늘막 (CYCLORAMA)