



- 23. 하늘막 (CYCLOPAMA)
- 22. 플막 2 (#2 DRAW CURTAIN)
- 21. 장치봉 (SET BATTEN)
- 20. 하늘막상단조명 + 다리막 (UPPER CYC. LIGHT + HOUSE BORDER)
- 18, 19. 다리막 5, 6 - 우좌측 (#5, #6 HOUSE LEGS RIGHT&LEFT SIDE)
- 17. 후면음향반사판 (ACOUSTICAL SHELL - BACK WALL)
- 16. 천장음향반사판 2 (#2 ACOUSTICAL SHELL - CEILING)
- 14, 15. 측면음향반사판 1, 3 (#1, #3 ACOUSTICAL SHELL - SIDE WALL)
- 13. 조명봉 2 (#2 LIGHT BATTEN)
- 12. 보더라이트 2 (#2 BORDER LIGHT)
- 10, 11. 다리막 3, 4 - 우좌측 (#3, #4 HOUSE LEGS RIGHT&LEFT SIDE)
- 09. 천장음향반사판 1 (#1 ACOUSTICAL SHELL - CEILING)
- 07, 08. 측면음향반사판 2, 4 (#2, #4 ACOUSTICAL SHELL - SIDE WALL)
- 06. 조명봉 1 (#1 LIGHT BATTEN)
- 05. 보더라이트 1 (#1 BORDER LIGHT)
- 03, 04. 다리막 1, 2 - 우좌측 (#1, #2 HOUSE LEGS RIGHT&LEFT SIDE)
- 02. 플막 1 (#1 DRAW CURTAIN)
- 01. 현수막판 (PLACARD PANEL)
- 00. 영점선 (ZERO LINE)

- 01. 좌측 천장조명 (CEILING LIGHT BATTEN - LEFT SIDE)
- 02. 우측 천장조명 (CEILING LIGHT BATTEN - RIGHT SIDE)
- 03. 천장조명 (CEILING LIGHT BATTEN)